




2025-12-01 / V1.2 / EN



High Voltage Battery System

Battery-Box HVE

6.4, 8.5, 10.7, 12.8-1, 12.8-2,
15.0, 17.1-1, 19.2, 17.1-2, 19.3, 21.4, 23.5

User Manual



iOS



Android

Copyright©2023 BYD Co., Ltd. All Rights Reserved.

Legal Provisions

All information in this document is the property of BYD Lithium Battery Co., Ltd. (herein after "BYD") and no part of this document may be reproduced in any manner for commercial use.

BYD makes no representations or warranties, express or implied, with respect to this document or any equipment and/or software that may be described in it, including (without limitation) any implied warranties of utility, merchantability or fitness for any particular purpose, and all such representations or warranties are expressly disclaimed. In no event shall BYD or its distributors or dealers be liable for any indirect, incidental or consequential damages.

Under some statutes, the exclusion of implied warranties may not apply in all cases, so the above exclusion may not apply.

Before transporting, storing, installing, operating, using, deactivating, or/and maintaining the equipment, please read this installation manual, strictly follow the contents of the installation manual, and follow all safety precautions indicated on the equipment and in the installation manual. In this installation manual, "equipment" refers to the products, software, components, spare parts, and/or services related to this installation manual.

The "Danger", "Warning", "Caution", and "Notice" items in the installation manual do not represent all the safety precautions that should be followed. You also need to comply with relevant international, national, or regional standards, as well as industry practices.

This equipment should be used in an environment that meets the design specifications. Otherwise, equipment failures, abnormal equipment functions, or component damage that may occur are not within the scope of equipment quality assurance; Otherwise, Shenzhen BYD Electronics Co., Ltd. shall not be liable for compensation for potential personal injury, property damage, etc.

All operations such as transportation, storage, installation, operation, use, shutdown, and maintenance should comply with applicable laws, regulations, standards, and specifications.

Reverse engineering, decompilation, disassembly, adaptation, implantation, or other derivative operations of device software are prohibited. It is not allowed to study the internal implementation logic of the device, obtain the source code of the device software, or infringe intellectual property rights in any way. It is also not allowed to disclose the results of any device software performance testing.

This document does not supersede and is not intended to supersede any local, state, provincial, federal, or national laws, regulations, or codes applicable to the installation, electrical safety, and use of the battery module. BYD is not responsible for compliance or non-compliance with such laws or regulations when installing the battery module.

Specifications are subject to change without notice. Every effort has been made to keep this document complete, accurate and current. However, without advance notice, BYD may need to make some improvements in specific situations. BYD shall not be liable for any damage caused by this document, including but not limited to omissions, errors, typographical errors, miscalculations, or tabulation errors in this document.

All trademarks are recognized.

Limited Warranty Letter

You can download the latest warranty documents from the www.bydenenergy.com on the Internet.

Product Datasheet

You can download the latest Product Datasheet from the www.bydenenergy.com on the Internet.

Service Guide

You can download the latest Service Guide from a www.bydenenergy.com on the Internet.

BYD Lithium Battery Co., Ltd.

No. 3001 Baohe Road, Baolong Industrial City, Longgang Street, Longgang District, ShenZhen.

Manufacturer

Shanwei BYD Auto Co., Ltd.

Xinhe Industrial Park, Luhe, Shanwei, P.R.China.

Table of Contents

1 Information on this Document	6
1.1 Validity	7
1.2 Target Groups	7
1.3 Content and Structure of this Document	7
1.4 Loading and Unloading Requirements	7
1.5 Transport Requirements	8
1.6 Declaration of Conformity	8
1.7 Warning Level	8
1.8 Documentation Symbols	9
1.9 Abbreviations and Definitions of Terms	9
2 Security	10
2.1 Intended Use	10
2.2 Important Safety Instructions	11
2.2.1 Battery Module Leakage	11
2.2.2 Firefighting Measures	12
2.2.3 Battery Modules Handling and Storage Guide	12
2.2.5 Warning of Overvoltage	14
2.2.6 Caution of Weight	14
2.2.7 Notice of Property Damage	15
3 Scope of Delivery	16
3.1 BCU and Base Package	16
3.2 Battery Module Package	16
3.3 Optional Accessories Package	16
4 Battery System Overview	17
4.1 Structure Dimension Drawing	17
4.2 Battery System Description	17
4.3 Battery System Scalability	18
4.4 Interface	19
4.5 Symbols	20
4.6 Nameplate Label	21
Warning Labels	22
4.7 LED Indicator	23
5 Installation	24

5.1 Instruction	24
5.1.1 Installation Requirements	24
5.1.2 Emergency Measures for Battery Falling	24
5.1.3 Installation and Operating Environment	24
5.1.4 Tools & Additional Accessories	27
5.1.5 Safety Gear & Required Personnel	28
5.2 Pre-installation Checking	28
5.3 Quantity and Location of Hanger	29
5.4 Floor Installation	30
5.5 Wall Mount (Optional)	33
6 Electrical Connections	35
6.1 Functional area overview	35
6.2 Topology Diagram	36
6.2.1 One Battery System	36
6.2.2 Two Battery Systems	37
6.2.3 Three Battery Systems	37
6.3 Grounding Connection	38
6.4 Data Cable Connection	39
6.4.1 Inverter Cable Connection Between Inverter and One Battery System	39
6.4.2 Data Cable Connection Between Multiple Towers	41
6.4.3 Installation Terminal Resistor	42
6.5 DC Connection	42
6.6 BYD Smart WIFI/LAN Module Installation (Optional)	45
6.6.1 BYD Inverter + HVE	45
6.6.2 Installation Procedure	45
LED Status and Key Operation of Smart WiFi/LAN Module	47
7 Configuration	48
7.1 Open the Battery System	48
7.2 Configuration of Battery System	49
7.3 Turn on and Commission the Inverter	49
7.3.1 On-grid applications	49
7.3.2 Off-grid Applications	50
8 Operation	51
8.1 Start the Battery System	51
8.1.1 Grid-connected applications	51
8.1.2 Black start function	52
8.2 Shut Down the Battery System	53
8.3 Safety Design	54

8.4 Protective Devices 54

9 Disassembly 55

10 Capacity Expansion 57

11 Fault Guide 58

 11.1 LED Failure Indication 58

 11.2 Service Guide 58

12 Storage 59

13 Maintenance and Replacement 60

14 Disposal of Battery Module 62

15 Technical Parameters 63

16 Contact Information 65

1 Information on this Document

Disclaimer

When installing, operating, and maintaining the equipment, read this manual first and follow all safety precautions in the equipment and manual.

BYD shall not be liable for any of the following circumstances.

- Equipment damage caused by force majeure events such as earthquakes, floods, volcanic eruptions, mudslides, lightning strikes, fires, wars, armed conflicts, typhoons, hurricanes, tornadoes, extreme weather, etc;
- Do not operate under the conditions described in this manual;
- The installation and use environment does not comply with relevant international, national, or regional standards;
- Non qualified personnel carry out equipment installation and use;
- Not following the operating instructions and safety warnings in the product and documentation;
- Unauthorized disassembly, alteration of products, or modification of software code;
- Damage caused by you or your authorized third-party transportation;
- Damage caused by storage conditions not meeting product documentation requirements;
- The materials and tools you provided do not meet the requirements of local laws, regulations, and relevant standards;
- Damage caused by your or a third party's negligence, intent, gross negligence, improper operation, or reasons not attributable to our company;

* Reverse engineering, decompilation, disassembly, adaptation, implantation, or other derivative operations of the device software are prohibited. It is forbidden to study the internal implementation of the device, obtain the source code of the device software and steal intellectual property rights in any way. It is forbidden to disclose any performance test results of the equipment software.

1.1 Validity

This document is valid for the Battery-Box HVE 6.4, 8.5, 10.7, 12.8-1, 12.8-2, 15.0, 17.1-1, 19.2, 17.1-2, 19.3, 21.4, 23.5.

1.2 Target Groups

The instructions in this document may only be performed by qualified personnel with the following skills:

- Knowledge of how batteries work and are operated.
- Knowledge of working principle and operation method of the inverter.
- Knowledge of, and adherence to the locally applicable connection requirements, standards, and directives.
- Knowledge of, and adherence to this document and the associated system documentation, including all safety instructions..
- Trained in dealing with the hazards associated with the installation and operation of electrical equipment and batteries.
- Training on installation and commissioning of electrical equipment.
- Personnel involved in special scenarios such as high-altitude operations and special equipment operations must have special operation qualifications required by the local country/region.
- Failure to do so will void any manufacturer's warranty, guarantee, or liability unless you can prove that the damage was not due to non-compliance.

1.3 Content and Structure of this Document

This document contains safety information and instructions, scope of delivery, battery system overview, installation, electrical connection, commissioning, operation, decommissioning, expansion, troubleshooting, maintenance and storage, battery system disposal, technical parameters and contact information. Read this document before performing any actions on the battery system.

1.4 Loading and Unloading Requirements

Batteries need to be handled in accordance with local laws, regulations and industry standards. Improper loading and unloading can result in shorting or damage to the battery, which can lead to leakage, rupture, explosion, or fire.

1.5 Transport Requirements

- Before shipment, the battery must be checked to ensure that it is intact and free from unusual odors, smoke, fire, etc. Otherwise, shipment is prohibited.
- Packing must be secure. The product must be handled with care during transportation, and moisture-proof measures shall be taken. Considering the influence of external environment (such as temperature, transportation, storage, etc.), the specifications and parameters shall be subject to the date of manufacture.
- The following conditions must be prohibited during transportation: direct contact with rain, snow or immersion in water; falling or mechanical shock; inverted or tilted.

1.6 Declaration of Conformity

The battery system described in this document comply with applicable local directives. The certificate is available in the Downloads area of the www.bydenergy.com.

1.7 Warning Level

The following levels of warning messages may appear when handling the battery system.



DANGER

Indicates a hazardous situation that, if not avoided, will result in death or serious injury.



WARNING

Indicates a hazardous situation which, if not avoided, could result in death or serious injury.



CAUTION

Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

NOTICE

Indicates a situation that could result in property damage if not avoided.

1.8 Documentation Symbols

 QUALIFIED PERSON
Describe activities performed by qualified personnel only.

1.9 Abbreviations and Definitions of Terms

No.	Designation	Explanation
1	HVE	BYD Battery-Box HVE
2	BCU	Battery Control Unit
3	BIC	Battery Information Collector
4	BMS	Battery Management System
5	BMU	Battery Management Unit
6	BYD	BYD Lithium Battery Co., Ltd.
7	SOC	State of Charge
8	Smart WIFI/LAN Module	For detailed operation, please refer to the Quick Guide of the Smart WIFI/LAN Module

2 Security

Disclaimer

BYD shall not be liable for any functional failure, component damage, personal safety accident or property loss caused by the following reasons:

- The customer fails to charge the battery in time, resulting in loss of battery capacity or other irreversible damage.
- Falling, leaking or other damage caused by improper handling or connection.
- The user does not set the battery operation management parameters correctly.
- The customer or third party changes the battery usage scenario without consulting BYD.
- Mix the batteries provided by BYD with other batteries, including but not limited to: mixing with batteries of other brands, mixing with batteries of different rated capacities, etc.
- The working environment or external power supply parameters can not meet the requirements of the normal working environment, causing direct damage to the battery.
- The customer has not properly maintained the battery in accordance with the owner's manual.
- Out of warranty batteries.
- Battery damage due to the use of an inverter other than BYD.
- Do not use accessories with recommended specifications.

2.1 Intended Use

Battery-Box HVE work with photovoltaic systems for residential use. It is a high-voltage lithium-ion battery storage system with a control module that can operate in on-grid, off-grid, and backup modes via compatible inverter.

The battery system doesn't have wireless communication function, it is connected with the Smart WiFi/ LAN Module to implement wireless functionality, and the Smart WiFi/ LAN Module has obtained network security certification.

The battery system can be connected to the Internet via Smart WiFi/LAN Module component on the inverter for maintenance and firmware updates.

The battery system can only be used as a fixed device.

The battery system is suitable for indoor and outdoor use under the conditions described in

Section 5.1.

The battery system can only be operated with a compatible inverter.

Model of inverter supported by energy storage

BYD Power-Box SH3-6K

BYD Power-Box TH5-15K

The battery system is not suitable for:

- Powering life-sustaining medical equipment;
- Train, elevator and other control equipment may cause personal injury;
- Computer systems of social and public importance;
- Location near medical equipment;
- Equipment similar to that described above.

Please ensure that no personal injury would occur due to the power outage of the battery system.

Alterations, such as alterations or modifications, to the battery are not permitted unless written permission is obtained from BYD. Unauthorized changes will invalidate warranty and warranty claims.

BYD shall not be liable for any damage caused by such changes. The type label should always be attached to the battery module.

2.2 Important Safety Instructions

The battery system are designed and tested to meet international safety requirements. However, to prevent personal injury and property damage and to ensure long-term operation of the battery system, please read this section carefully and always observe all safety information.

2.2.1 Battery Module Leakage

If the battery module leaks electrolyte, avoid contact with the leaking liquid or gas. Electrolyte is corrosive and may cause skin irritation and chemical burns on contact. If you come in contact with leaking material, perform the following steps:

Accidental inhalation: Evacuate the contaminated area and seek medical attention immediately.

Eye exposure: Rinse eyes with running water for 15 minutes and seek immediate medical attention.

Skin contact: Wash the affected area thoroughly with soap and water and get medical help immediately.

Ingestion: Induce vomiting and seek medical help immediately.

2.2.2 Firefighting Measures

When the battery module is put into a fire, the battery module may catch fire. In the event of a fire, make sure there is an ABC or CO₂ fire extinguisher nearby. Do not use water to extinguish the fire. Firefighters need to wear full protective clothing and self-contained breathing apparatus when fighting fires.

2.2.3 Battery Modules Handling and Storage Guide

The battery module and its components shall be protected from damage during transportation and handling.

- Do not hit, pull, or step on the battery module.
- Do not insert extraneous objects into any part of the battery module.
- Do not place the battery module in a fire.
- Do not immerse the battery module in water or seawater.
- Do not handle strong oxidizing agents.
- Do not short-circuit the battery module.
- The battery module cannot be stored at high temperatures ($\geq 50^{\circ}\text{C}$).
- The battery module cannot be stored directly in the sun.
- The battery module cannot be stored in a high humidity environment.
- Do not use cleaning solvents to clean battery module.
- Do not open or damage the battery. The released electrolytes are harmful to the skin and eyes and should be avoided.
- Do not stand, lean, or sit on the battery.
- Before touching any conductor surface or terminal, measure the voltage at the point of contact to confirm that there is no risk of electric shock.

- The terminal shall not be damaged during transportation. It is forbidden to lift the battery through the terminal bolt.
- Batteries must be stored separately in the package. Avoid storing the battery with other items. It is strictly prohibited to store in the open air and stack too high.
- Do not use a damaged battery (dropped, bumped, or otherwise damaged, such as a dent in the case).
- Do not store a damaged battery near a good product. Damaged battery storage locations shall not contain flammable materials. Only professionals can access it.
- Damaged batteries should be monitored during storage to ensure there are no signs of smoke, flame, electrolyte leakage, or heat.

2.2.4 Electric Shock Warning



Danger to life due to electric shock when live components or DC cables are touched

The DC cables connected to an inverter may be live. Touching live DC cables results in death or serious injury due to electric shock.

- Disconnect the battery system and inverter from the voltage source and mark to ensure that they cannot be reconnected before operating the equipment.
- Do not touch non-insulated parts or cables.
- Do not remove the terminal block with the connected power wire from the slot under load.
- Wear appropriate personal protective equipment when performing all work on the battery system.
- Comply with all safety information from the inverter manufacturer.

2.2.5 Warning of Overvoltage



Danger to life due to electric shock in case of overvoltages and if surge protection is missing

Overvoltages (e.g. in the event of a flash of lightning) can be further conducted into the building and to other connected devices in the same network via the network cables or other data cables if there is no surge protection. Touching live parts and cables results in death or lethal injuries due to electric shock.

- Ensure that all devices and inverters in the same network are integrated into the existing surge protection.
- When laying network cables or other data cables outdoors, it must be ensured that a suitable surge protection device is provided at the transition point of the cable from the outdoor battery system or inverter to the interior of the building.

2.2.6 Caution of Weight



Risk of injury due to weight of the battery module

Injuries may result if the battery module is lifted incorrectly or dropped while being transported or installed.

- Carefully transport and lift the battery module. Consider the weight of the battery module.
- Wear appropriate personal protective equipment when performing all work on the battery system.

2.2.7 Notice of Property Damage

NOTICE

Damage to the BCU due to sand, dust and moisture ingress

Sand, dust and moisture penetration can damage the BCU and impair its functionality.

- Only open the BCU if the humidity is within the thresholds and the environment is free of sand and dust.


NOTICE

Damage to the battery system due to under voltage


- If the battery system does not start at all, please contact BYD's local after-sales service team within 48 hours. Otherwise, the battery may be permanently damaged.

3 Scope of Delivery


3.1 BCU and Base Package



3.2 Battery Module Package




3.3 Optional Accessories Package




4 Battery System Overview

The Battery-Box HVE is used as a connected battery for the intermediate storage of excess PV energy in an inverter system.


4.1 Structure Dimension Drawing



4.2 Battery System Description



4.3 Battery System Scalability



One to four battery modules form a tower (Maximum: 3 x module6.4 + 1 x module4.2) , and up to 3 tower can be connected in parallel.

4.4 Interface

BYD Energy

Through the APP, you can realize intelligent battery management, including remote data monitoring, firmware upgrade and troubleshooting.

- Android users: Search for “BYD Energy” on Google Play or scan Android QR code to download and install.
- iPhone users: Search for “BYD Energy” in the App Store or scan iOS QR code to download and install.



iOS



Android

Configuration steps:



The battery system doesn't have a wireless communication function. Through the USB, the battery system supports the expansion of connection with the Smart WiFi/LAN Module to implement the wireless function, and the Smart WiFi/ LAN Module had obtained individual cyber security certification in accordance with EN 18031 series.

For detailed configuration steps, please refer to the user manual and APP instructions,

Website: www.bydenery.com.

Scan the QR code below to obtain the corresponding video manual. ▶



4.5 Symbols

Symbol	Explanation
	Observe the documents Observe all documents supplied with the system.
	Separate collection symbol Do not dispose of used batteries with other waste. Instead, collect and recycle them separately in accordance with Regulation (EU) 2023/1542.
	Separate collection symbol (WEEE) Do not dispose of the system together with the household waste but in accordance with the disposal regulations for electronic waste applicable at the installation site.
	CE marking The system complies with the requirements of the applicable EU directives.
	Keep the battery modules away from open flame or ignition sources.
	Beware of electrical voltage.
	Beware of a danger zone This symbol indicates that the system must be additionally grounded if additional grounding or equipotential bonding is required at the installation site.
	Keep the battery modules away from children.
	Grounding conductor This symbol indicates the position for connecting a grounding conductor.
	This side up.
	Handle with care.
	Keep dry.
	RCM (Regulatory Compliance Mark) The system complies with the brief guide to electrical equipment approvals in Australia.
	The product has been tested and certified by TUV Rheinland.

4.6 Nameplate Label

BCU Labels

Rechargeable Li-ion Battery System
Battery-Box



Model:	HVE 6.4	HVE 8.5	HVE 10.7	HVE 12.8-1	HVE 12.8-2	HVE 15.0
Usable Energy(kWh):	6.43	8.58	10.72	12.86	12.87	15.01
Nominal Voltage(V):	115.2	153.6	192.0	230.4	230.4	268.8

Model:	HVE 17.1-1	HVE 19.2	HVE 17.1-2	HVE 19.3	HVE 21.4	HVE 23.5
Usable Energy(kWh):	17.15	19.29	17.16	19.30	21.44	23.58
Nominal Voltage(V):	307.2	345.6	307.2	345.6	384.0	422.4

Rated Capacity: 55.8Ah Overvoltage Category: II Chemistry: LiFePO₄ IP Class: IP65
Protective Class: I Max. Charge/Discharge Current: 35A Operating Temperature: -20°C~+55°C

Manufacturer: Shanwei BYD Auto Co., Ltd.
Address: Xinhe Industrial Park, Luhe, Shanwei,
P.R.China
E-Mail: bboxservice1@fdbatt.com
Website: <http://www.bydenenergy.com>


 Type Approved
 Safety
 Regular Production
 Surveillance
 www.tuv.com
 ID 1111299451












MADE IN CHINA

Rechargeable Li-ion Battery System
Battery-Box



Model:	☐ HVE 6.4	☐ HVE 8.5	☐ HVE 10.7	☐ HVE 12.8-1	☐ HVE 12.8-2	☐ HVE 15.0
Usable Energy(kWh):	6.43	8.58	10.72	12.86	12.87	15.01
Nominal Voltage(V):	115.2	153.6	192.0	230.4	230.4	268.8

Model:	☐ HVE 17.1-1	☐ HVE 19.2	☐ HVE 17.1-2	☐ HVE 19.3	☐ HVE 21.4	☐ HVE 23.5
Usable Energy(kWh):	17.15	19.29	17.16	19.30	21.44	23.58
Nominal Voltage(V):	307.2	345.6	307.2	345.6	384.0	422.4

Battery Module Labels

Rechargeable Li-Ion Battery Battery-Box HVE Module Model: HVE 6.4 Module Nominal Voltage(V): 115.2 Voltage Range(V): 90~131.4 Max. Charge / Discharge Current(A): 35 Usable Energy(kWh): 6.43 Rated Capacity(Ah): 55.8 Operating Temperature(°C): -20~+55 IP Class: IP65 Protective Class: I Weight(kg): 61.6 Chemistry: LiFePO₄ IP6P41/150/105/1P36SJM/-20+50/90 Manufacturer: Shanwei BYD Auto Co., Ltd. Address: Xinh Industrial Park, Luhe, Shanwei, P.R.China EXTINGUISHING MEDIA: DRY POWDER, SAND, CARBON DIOXIDE(CO₂)	         MADE IN CHINA
--	--

Rechargeable Li-Ion Battery Battery-Box HVE Module Model: HVE 4.2 Module Nominal Voltage(V): 76.8 Voltage Range(V): 60~87.6 Max. Charge / Discharge Current(A): 35 Usable Energy(kWh): 4.29 Rated Capacity(Ah): 55.8 Operating Temperature(°C): -20~+55 IP Class: IP65 Protective Class: I Weight(kg): 42.6 Chemistry: LiFePO₄ IP6P41/150/105/1P24SJM/-20+50/90 Manufacturer: Shanwei BYD Auto Co., Ltd. Address: Xinh Industrial Park, Luhe, Shanwei, P.R.China EXTINGUISHING MEDIA: DRY POWDER, SAND, CARBON DIOXIDE(CO₂)	         MADE IN CHINA
--	--

Warning Labels






⚠ WARNING

1. For the transportation, storage, installation, operation and maintenance of the lithium-ion battery, please strictly follow the contents of the user manual. If any faults are found in the lithium-ion battery, immediately take it out of service and contact the manufacturer's customer service department.
2. Do not place any foreign objects or tools on the lithium-ion battery to prevent short-circuit. When installing or removing the lithium-ion battery, there is a risk of electrical accidents and injuries.
3. Do not short-circuit the battery or reverse its polarity. Keep it out of direct sunlight. Keep it away from strong heat sources or fire. Improper use may cause damage to the battery or even cause combustion, which can be extremely dangerous.
4. Lithium-ion batteries that are damaged or in uncertain conditions shall only be handled by specially trained and authorized lithium-ion battery technicians. When handling or servicing lithium-ion batteries that are damaged or in uncertain conditions, wear Personal Protective Equipment (PPE) (e.g. safety goggles, a gas mask, safety gloves, safety shoes, and a helmet) and follow the manufacturer's instructions.

NOTICE

If a lithium-ion battery is not used for a long period of time, it can become damaged through over-discharge. Recharge the battery at least every 6 months, including during storage. When the battery is fully discharged, it should be recharged within 7 days.

4.7 LED Indicator

Indicator	Status	Description
Flashing white and blue alternatively	White ☐ ON OFF Blue ☒ ON OFF 	The battery system is initiating
Flashing white slowly	White ☐ ON OFF Blue ☒ ON OFF 	The battery system is charging
White light flashing	White ☐ ON OFF Blue ☒ ON OFF 	The battery system is discharging
Constant white	White ☐ ON OFF Blue ☒ ON OFF 	Idle (the battery system is either charging nor discharging).
Constant blue	White ☐ ON OFF Blue ☒ ON OFF 	BCU failure
Blue light flashes a certain number of times	White ☐ ON OFF Blue ☒ ON OFF 	Counting from top to bottom, flashing N times, represents the Nth battery module failure, N represents 1-4 battery modules



The specific logic of LED lights can be found in the Service Guideline and Checklist.

The LED light will turn off without any operation during the 12 hour normal operation.

5 Installation

5.1 Instruction

5.1.1 Installation Requirements

- It is strictly prohibited to install, use and operate outdoor equipment and cables (including but not limited to handling equipment, operating equipment and cables, plugging and unplugging signal interfaces connected to the outdoors, working at heights, outdoor installation, opening doors, etc.) in severe weather such as lightning, rain, snow and strong winds above force 6.
- Before installing the battery, check that the packaging is intact. Batteries with damaged packaging cannot be used.
- Pay attention to the positive and negative terminals during installation. Do not short the positive and negative terminals.
- Be sure to tighten the screws during installation and check them regularly.
- After installation, the remaining packing materials, such as packaging, foam board, plastic, ties, etc., should be removed.

5.1.2 Emergency Measures for Battery Falling


- When installing the battery, dropping or mechanical shock may cause internal damage to the device. If these situations occur, it is strictly prohibited to continue to use, otherwise it may cause potential safety hazards.
- After the battery is dropped, if there is obvious smell, damage, smoke, fire and other phenomena, immediately evacuate the personnel and contact professionals. Use fire fighting facilities to extinguish fire under the guidance of professionals.
- After the battery is dropped, if there is no obvious smell, smoke or fire, and there is no obvious deformation or damage, please contact a professional to move it to an open and safe place or contact a recycling company for disposal.

5.1.3 Installation and Operating Environment

- The installation and operating environment needs to comply with local laws and relevant international, national and regional standards for lithium-ion products.
- It is the duty of the person using the equipment to protect it from fire or other damage.
- A solid supporting surface (such as concrete or masonry) must be provided.








- The installation position shall not be entered or touched by children, and shall be far away from daily work, living and other areas.
- The mounting location must be suitable for the weight and dimensions of the battery system.
- The installation location shall not be exposed to direct sunlight, rain and snow.
- The level of the installation site shall be higher than highest water level in the history of the area and at least 300 mm above the ground. The installation site shall not be located in low-lying areas.
- The installation position shall be far away from the fire source and heat source, and inflammable and explosive articles shall not be placed around the equipment.
- Garage installation shall be away from the direction of the vehicle. It is recommended to install the energy storage wall higher than bumper of the vehicle body to avoid accidental collision.
- It is forbidden to install in places that are airtight, unventilated, without proper fire fighting facilities or difficult for firefighters to reach.
- It is forbidden to be installed in moving scenes such as ships, trains and automobiles.
- For areas with frequent natural disasters such as floods, debris flows, earthquakes and typhoons, corresponding preventive measures should be taken for installation.
- It is forbidden to install and operate the equipment beyond the scope specified in the technical indicators, otherwise the performance and safety of the equipment will be affected.
- Wall-mounted walls must be solid and load-bearing (such as concrete or masonry).
- The altitude of the installation location shall be less than 4000 meters.
- The ambient temperature shall be between -10°C and + 50°C.
- The ambient humidity should be between 5% and 95%. Energy storage will be corroded when installed in salt areas. Do not install it outdoors in salt areas. Salt damage area refers to the area within 500m from the coast or affected by the sea breeze. The area affected by the sea breeze varies according to meteorological conditions (e.g. typhoon, seasonal wind) or topography (with dams, hills).
- The distance between the back of the installation position and the wall shall be 19 ~ 44mm.
- The distance from the side of the installation position to the wall shall be greater than 300 mm.

- The distance between systems at the installation position shall be 300 ~ 600mm.
- The minimum distance that the battery needs to maintain from heat sources is 2 meters.



5.1.4 Tools & Additional Accessories

You may need to use the tools in the following table during the installation process, which are not included in the scope of delivery.

					
Wire Stripper	Network wire clamp	Rubber mallet	Phillips Screwdriver Bit	Wrench	
					
Knife	Gradienter	Tape measure	DC terminal crimping tool	Heat gun	
					
Hydraulic clamp	Pen	Drill	Hexwrench	Torque Wrench	
 Recommended use batteries ≥3  Ladder or  Lifting device  					
					
DC Cable 10AWG / 6mm ² Ø:5.2-6mm	RJ45 Connector	Data Cable CAT5E Ø:5-6mm	OT Terminal 6mm ² -M5	PE 10AWG / 6mm ²	Heat shrink tube Ø:6-8mm

5.1.5 Safety Gear & Required Personnel



5.2 Pre-installation Checking

! QUALIFIED PERSON

! DANGER

Danger to life from electric shock due to live DC cables or connectors at the battery system

The DC cables connected to the battery system may be live. Touching the DC conductors or the live components leads to lethal electric shocks.

- Do not touch non-insulated cable ends.

! CAUTION

Risk of injury due to weight of the battery module

Injuries may result if the battery module is lifted incorrectly or dropped while being transported or installed.

- Carefully transport and lift the battery module. Consider the weight of the battery module.
- Wear appropriate personal protective equipment when performing all work on the battery module. work on the battery system.

Inspection before installation:


Product packaging: Before removing the energy storage packaging, inspect the packaging for visible damage, such as holes, cracks, or other internal signs of possible damage, and check the energy storage model. If there is any abnormal packaging or the energy storage model does not match, do not open it and contact your dealer as soon as possible.

Inspection of deliverables: After unpacking the energy storage overpack, check the deliverables for completeness and for any visible external damage. If any items are missing or if there is any damage, contact your dealer.



Please refer to Chapter 3 for the deliverables.

5.3 Quantity and Location of Hanger



Please install on top and/or bottom battery!



When ≥ 3 modules are installed, 4 hangers must be used!

 Number of Hanger	Number of Modules	1~2	3~4
	Floor Stand	Hanger x 2	Hanger x 4
	Wall Mount	Hanger x 2	Hanger x 4

5.4 Floor Installation




The bearing capacity of the ground must be greater than or equal to 800kg/m^2 .

Steps:


Install the feet

1. Open the box and remove the BCU, Base and accessories.
2. Install the feet to the base.
3. Please follow the **LEFT** and **RIGHT** markings on the base, put the battery module along the wall, and keep a distance of 19~44mm.
4. Adjust the support feet with the help of a spirit level (**Tilt is not allowed!**).




Install the module

1. Remove the battery module from its packaging using handles.
- 2~3. Install battery module on the base. **(There is electricity in the blind socket, please do not touch it!)**



4. Fasten battery module to the Base by screws M5.
- 5~6. Remove the handle and M6 screw. **(Suggest placing the M6 screw properly for future maintenance and use)**
7. Install the rubber plug at the position where the handle screw was removed.
8. Stack the battery modules one by one. **(When installing multiple modules with different power levels, it is recommended to place the HVE6.4 module below)**
9. Install the BCU on top of the battery module.





When it is necessary to install 3 or more battery modules in one tower, it is recommended to connect the cables on the BCU first. Please refer to Chapter 6 for detailed cable connection procedure.

10. Fasten the BCU to the battery module by screws M5.

11. Mark the position of the drill holes.

12. Drill holes at the marked locations.




Please note that there may be power cables or other power supply lines (such as gas or water) in the wall. When drilling, you may damage the lines. Please make sure that there are no lines on the wall first.

13. Hammer the two expansion screws into the holes with a rubber mallet.

14. Fasten hangers to the battery module by M6 screws.

15. Then fix the battery module to the wall.



5.5 Wall Mount (Optional)



Concrete walls and brick walls are recommended!


Steps:

1. Use a marking card to mark the position of the drilling hole.
2. Drill holes at the marked locations.



Please note that there may be power cables or other power supply lines (such as gas or water) in the wall. When drilling, you may damage the lines. Please make sure that there are no lines on the wall first.


3. Hammer the two expansion screws into the holes with a rubber mallet.



- 4-5. Please follow the **LEFT**, **MIDDLE** and **RIGHT** markings on the bracket, Fasten bracket to the Base by screws M10.


6. Fix the bracket on the wall.

- 7-8. Install the trim cover and secure with the plastic rivets plug.




9~10. Refer to the module and BCU installation method to install the module and BCU.

11. Storing the handle on the back of the BCU.



12. Mark the product type.

After installation, please ask the installation personnel to check the corresponding model on the label.



Model	Number of Modules
HVE 6.4	1
HVE 8.5	2
HVE 10.7	2
HVE 12.8-1	2
HVE 12.8-2	3
HVE 15.0	3
HVE 17.1-1	3
HVE 19.2	3
HVE 17.1-2	4
HVE 19.3	4
HVE 21.4	4
HVE 23.5	4


NOTICE

Damage to the battery system due to under voltages

- If the battery is installed, it should be set into operation within a month, or checked regularly, otherwise there might be damage to the batteries.

6 Electrical Connections

6.1 Functional area overview




No.	Terms	Description
①	MAIN Switch	Power on/power off.
②	P+	Connect to positive terminal of external device.
③	P-	Connect to negative terminal of external device.
④	COM—INV	Port for data cable in, Connect to inverter.
	COM—OUT	Port for data cable out, for battery parallel connection.
	COM—IN	Port for data cable in, for battery parallel connection.
⑤	WIFI	Port for smart WIFI/LAN Module.
⑥	Grounding	Grounding connection.

6.2 Topology Diagram




The distance between systems is 300-3000mm.


6.2.1 One Battery System



6.2.2 Two Battery Systems



6.2.3 Three Battery Systems



6.3 Grounding Connection

When installing, the grounding wire must be installed first; when removing the equipment, the grounding wire must be removed last.


Additional required installation materials (not included in the scope of delivery): PE with terminals.

PE and terminal requirements:


- Terminals, 5mm.
- Minimum terminal cross-section: 10AWG / 6mm²
- The cross section of the earth terminal must comply with the applicable local standards and directives.
- PE section $\geq 6 \text{ mm}^2$
- PE material: copper wire terminal
- OT-Termal: 6-5

Procedure:


1. Turn off the switch on the BCU.
2. Peel off the plastic of the grounding cable so that the stripped length (L in the figure below) is 9-10.5mm.
3. Thread the cable through the heat shrink tubing and insert the OT terminal onto the cable.
4. Squeeze the tube of the wire with a wire clamp.
5. Get the heat shrink tubing back to cover the connection part of the cable and the conductor.
6. Blow the heat shrink tubing with hot air.



7. Remove the nut from the grounding point, install the PE wire, and then tighten the original nut with a Phillips screwdriver (torque 5-6Nm).



6.4 Data Cable Connection



No.	1	2	3	4	5	6	7	8
INV	RS485A	RS485B	IGND	CAN_H	CAN_L	NC	PCS_EN+	PCS_EN-
IN/ OUT	Unused	Unused	Unused	Unused	Unused	Unused	CAN_L	CAN_H

6.4.1 Inverter Cable Connection Between Inverter and One Battery System

! QUALIFIED PERSON

Additional required installation materials (not included in the scope of delivery), one data cable
Data cable requirements:

i The length and quality of the cable affect the quality of the signal.


Observe the following cable requirements:

- Cable category: CAT5, CAT5e or higher
- Plug type: CAT5, CAT5e or higher metal shield RJ45
- Shield: Yes
- UV protection for outdoor use
- Straight-through cable
- Maximum cable length: 3 meters.

Procedure:

Read the inverter port name on the battery system and the inverter manual to decide whether to modify the data cable. The definition of the inverter port on the battery system can be seen above.

1. Detach the external cable gland.
2. Put the cable through all the part of the external cable glands and the wiring hole. Please cut the cable, arrange the cable position, and crimp the RJ45 connector with the network cable clamp.
3. Insert the RJ45 connector into the BCU INV port.
4. Assembling the external cable glands (torque, 1.2 Nm).
5. Insert the other end of the connector into the corresponding port of the inverter.



6.4.2 Data Cable Connection Between Multiple Towers

This only applies when there are multiple towers in parallel. Additional required installation materials (not included in the scope of delivery)




The length and quality of the cable affect the quality of the signal.

Observe the following cable requirements:

- Cable category: CAT5, CAT5e or higher
- Plug type: CAT5, CAT5e or higher metal shield RJ45
- Shield: Yes
- UV protection for outdoor use
- Straight-through cable
- Maximum cable length between two towers: 3 meters.

Procedure:

1. Detach the external cable gland.
2. Plug the RJ45 connector into the output port of the BCU of the first tower and into the input port of the BCU of the second tower.
3. Repeat step 2 for the following columns. Cover the terminal resistors on the multiple towers, refer to the 6.2.2-6.2.3 in this manual.
4. Assembling the external cable glands.



6.4.3 Installation Terminal Resistor

Procedure:

Insert the terminal resistors into the remaining input and output ports of the BCU. Two (2) or more BCU require two (2) terminal resistors.



Individual one battery system do not require terminal resistors.

6.5 DC Connection



QUALIFIED PERSON



DANGER

Danger to life from electric shock due to live DC cables or connectors at the battery system

The DC cables connected to the battery system may be live. Touching the DC conductors or the live components leads to lethal electric shocks.

- Do not touch non-insulated cable ends.

When connecting multiple towers, the length of the positive power cable should be approximately equal for all towers, and the negative power cable should also be approximately equal. A combiner box is required to combine these cables. Follow your local, state, provincial, federal, or national laws, regulations, and inverter manufacturer's instructions to select the appropriate combiner box.


Additional required installation materials (not included in the scope of delivery): Two DC cables (connecting battery system and inverter)

Cable requirements:

- Conductor section: 6mm². Select the correct option based on the application and the inverter manufacturer's requirements.
- Maximum cable length: 3 meters

Procedure:

1. Use wire strippers to strip the insulation layer of the positive and negative cables to an appropriate length.
2. Put the insulation layer of the positive and negative cables into the corresponding metal terminals, and crimp them tightly with crimping pliers.
- 3~6. Insert the crimped positive and negative cables into the corresponding insulating shells, Tighten the plastic nuts at the end of the insulating shell of the positive and negative connectors.
- 7~8. Remove the protection plugs of the positive and negative poles of the DC input terminal of the inverter. Insert the positive and negative connectors into the positive and negative poles of the DC input terminal of the inverter.




Outgoing line mode

There are two outlet modes:

C. Side outgoing line


D. Back outgoing line



6.6 BYD Smart WIFI/LAN Module Installation (Optional)

6.6.1 BYD Inverter + HVE

- The battery system doesn't have a wireless communication function. Through the USB, the battery system supports the expansion of connection with the Smart WiFi/LAN Module to implement the wireless function, and the Smart WiFi/ LAN Module had obtained individual cyber security certification in accordance with EN 18031 series.
- The communication stick is an accessory included with the inverter
- A household energy storage system requires only one communication stick.
- Communication rod is installed on the inverter.



6.6.2 Installation Procedure



QUALIFIED PERSON



DANGER

Danger to life due to electric shock in case of overvoltages and if surge protection is missing

Overvoltages (eg. in the event of a flash of lightning) can be further conducted into the building and to other connected devices in the same network via the network cables or other data cables if there is no surge protection. Touching live parts and cables results in death or lethal injuries due to electric shock.

- Ensure that all devices and inverters in the same network are integrated into the existing surge protection.
- When laying network cables or other data cables outdoors, it must be ensured that a suitable surge protection device is provided at the transition point of the cable from the outdoor battery system or inverter to the interior of the building.

Connection to the Internet is not mandatory, but is recommended. It can also be configured on BYD inverters

Additional required installation materials (not included in the scope of delivery):

- Smart WIFI/LAN Module


Procedure: Connect the Smart WiFi/LAN Module to the BCU

Installation option

There are two connect modes:

A. WIFI

B. Ethernet



LED Status and Key Operation of Smart WiFi/LAN Module

The LED status of Smart WiFi/LAN Module are shown as follows:

Indicator	Frequency	Status	Description
Bluetooth	On for 0.5s and then off for 0.5s	0.5s	Blinking slowly: The Bluetooth is not connected.
	Steady on		Steady on: The Bluetooth connection is successful.
	On for 0.1s and then off for 0.1s	0.1s	Blinking quickly: Bluetooth pairing mode.
Network	On for 0.5s and then off for 0.5s	0.5s	Blinking slowly: The Network is not connected.
	Steady on		Steady on: The Network connection is successful.
Bluetooth & Network	From steady on to blinking quickly,after 3 seconds,blinking slowly	3s 3s	steady on >>> blinking quickly >>> blinking slowly: Bluetooth and Network restore factory settings

The key operations of Smart WiFi/LAN Module are shown as follows:

Operation	Description
Press and hold for more than 10 seconds	Restore factory settings
press and hold for more than 3 seconds	Re-enter the distribution network status after completing the distribution network setup
Press and hold for more than 3 seconds	Reset the Bluetooth at Single Bluetooth connection mode

7 Configuration

7.1 Open the Battery System




Requirements:

- The power line connection between the battery system and the inverter must be closed.
- The inverter must be installed correctly.
- All cables must be properly connected.

Procedure:

1. Turn on the air switch between the battery and the inverter (if any).
2. Push the Main Switch from "OFF" to "ON".
3. The LED starts blinking for a while (0.5 seconds white and 0.5 seconds blue alternating) and then changes to white, which means the battery system is ready to work.
4. If the battery system cannot be opened, please read Chapter 11 Troubleshooting and Service Guide and Checklist. If the problem still cannot be solved, please contact our local after-sales service team within 48 hours.



7.2 Configuration of Battery System



Refer to the Inverter User Manual and **BYD Energy App Quick Operation Guide** for detail configuration steps.

Before configuring the battery system, please confirm that the BCU firmware is the latest version. If not, perform the firmware update on BYD Energy App first.

7.3 Turn on and Commission the Inverter

The steps are different for on-grid and off-grid applications.


7.3.1 On-grid applications

Procedure:

1. Install and connect the inverter according to its instructions.
2. Turn on the inverter.
3. Configure and debug the inverter according to the instructions of the inverter.

If the battery information can be read correctly on the inverter, it means that the connection is OK.

If the LED is blinking blue, and/or some battery errors are displayed on the inverter, refer to Chapter 11 Trouble-shooting in this manual and read the Service Guide and Checklist.




7.3.2 Off-grid Applications

Procedure:

1. Install and connect the inverter according to its instructions.
2. Turn on the air switch between the inverter and the battery (if there is one);
3. Turn on the inverter.
4. Turn on the battery system
5. **Black start:** press the LED button on the main system BCU for 3 seconds.
6. Configure and debug the inverter according to the instructions of the inverter.

If the battery information can be read correctly on the inverter, it means that the connection is OK.

If the LED is still blinking blue, and/or some battery errors are displayed on the inverter, refer to Chapter 11 Troubleshooting in this manual and read the Service Guide and Checklist.



8 Operation


8.1 Start the Battery System

8.1.1 Grid-connected applications

To ensure that the battery system works well with the inverter, follow the correct procedure to start them.

Procedure:

1. Turn on the air switch between the inverter and the battery (if there is one);
2. Turn on the battery system;
3. Turn on the inverter.




8.1.2 Black start function

To ensure that the battery system works well with the inverter, follow the correct procedure to start them.

Procedure:

1. Turn on the switch between the inverter and the battery (if there is one);
2. Turn on the battery system;
3. Switch on the inverter;
4. **Black start:** Press the LED button of the main system for 3 seconds.



8.2 Shut Down the Battery System


Procedure:

The procedure to switch off the battery system is:

1. Switch off the inverter;
2. Switch off the battery;
3. Switch off the air switch between the battery and the inverter if there is any.

The correct way to switch off the battery system is to press the LED Button for 5 seconds on the BCU, but not to pull down the air switch of BCU.

If two or three battery systems are connected in parallel, only the LED Button on the master system needs to be pressed. The slave system(s) will be turned off automatically.



8.3 Safety Design

When the battery system loses communication with the inverter, it can remain in standby mode for 24 hours; if the duration exceeds 24 hours, the battery system will shut down.

8.4 Protective Devices

If the HVE battery system configuration list is not met, the battery system can protect itself (shut down). If external protection is required, follow local, state, provincial, federal, or national laws, regulations, and the inverter manufacturer's instructions.

9 Disassembly



QUALIFIED PERSON



DANGER

Danger to life from electric shock due to live DC cables or connectors at the battery system

The DC cables connected to the battery system may be live. Touching the DC conductors or the live components leads to lethal electric shocks.

- Do not touch non-insulated cable ends.



CAUTION

Risk of injury due to weight of the battery module

Injuries may result if the battery module is lifted incorrectly or dropped while being transported or installed.

- Carefully transport and lift the battery module. Consider the weight of the battery module.
- Wear appropriate personal protective equipment when performing all work on the battery module.

Procedure:

1. Switch off the inverter.
2. Turn off the battery system.
3. Turn off the air switch (if any) between the inverter and the battery system.
4. Unplug all cables from the battery system.
5. Loosen the interlocking screw between the battery module and the BCU, and then remove the BCU.
6. Loosen the screws on the pull wall between the battery module and the wall, and then remove the pull wall.
7. Loosen the interlocking screws between the battery modules, and then remove the upper battery module (if any).
8. Loosen the interlock screw between the battery module and the base, and then remove the battery module.

9. Loosen the screws between the wall hanger and the base, loosen the screws between the wall hanger and the wall, and then remove the wall hanger (if any).

If you want to store or transport battery modules, modularize the system. Use the original packaging or packaging appropriate for the weight and dimensions of the system. Dispose of battery modules in accordance with applicable local e-waste disposal regulations.

10 Capacity Expansion


The battery module can be expanded at any time. The original SOC of the new battery module is around 30%. To avoid capacity loss, a SOC difference of approximately 5% is recommended. If the SOC difference is $>5\%$, the battery system will initiate self-adjustment of the SOC. The duration of self-adjustment depends on the SOC difference between the old and new battery module, with a maximum time not exceeding 30 days.

Steps:

1. Switch off the inverter..
2. Shut down the battery system.
3. Turn off the air switch (if any) between the inverter and the battery system
4. Remove the BCU.
5. Add the new module(s) on top of the other battery modules.
6. Place the BCU back on top of the new battery module.
7. Turn on and configure the battery system.
8. Switch on the inverter.

11 Fault Guide

11.1 LED Failure Indication

Indicator	Status	Description
Constant blue	White ☐ ON ☐ OFF Blue ☒ ON ☐ OFF	BCU failure
Constant blue and white light flashes a certain number of times	White ☐ ON ☐ OFF Blue ☒ ON ☐ OFF	 Flashing N times, represents the Nth battery module failure counting from top to bottom. HVS+: $1 \leq N \leq 5$; HVM+: $1 \leq N \leq 8$;
Flashing blue	White ☐ ON ☐ OFF Blue ☒ ON ☐ OFF	 The battery has entered a protective state
Flashing blue quickly	White ☐ ON ☐ OFF Blue ☒ ON ☐ OFF	 Exit System



Please refer to the "Fault List" for specific details

11.2 Service Guide

In addition to the LED light, we can also get the fault information of the battery through the mobile phone application. Please refer to the latest Service Guide for detailed steps. Website: www.bydenery.com.

The battery module cannot be turned on/off. Check that the system has been built according to the Battery module HVE Technical Information. If the problem still cannot be solved, please contact the local BYD after-sales service within 48 hours.

NOTICE

Battery module is damaged due to too low voltage.

- If the battery module does not start at all, please contact BYD's local after-sales service within 48 hours. Otherwise, the battery may be permanently damaged.

12 Storage

Cleaning

It is recommended that the battery system be cleaned periodically. If the enclosure is dirty, please use a soft, dry brush or a dust collector to remove the dust. Liquids such as solvents, abrasives, or corrosive liquids should not be used to clean the enclosure.

The battery module shall be stored in an environment with a temperature range from -10°C to +50°C and periodically charged according to the following table. After a long period of storage, the charging temperature shall not exceed 0.5C (C-rate is a measure of the rate at which a battery is charged and discharged relative to its maximum capacity) to 30% SOC.

Storage temperature	Storage humidity	Storage time	SOC
<-10°C	/	Not allowed	/
-10~25°C	5%~70%	≤ 12 months	20%≤SOC≤60%
25~35°C	5%~70%	≤ 6 months	25%≤SOC≤60%
35~50°C	5%~70%	≤ 3 months	20%≤SOC≤60%
Above 50°C	/	Not allowed	/

NOTICE

Module damage due to undervoltage.

- When the temperature is higher than 25°C, the overdischarged system shall be charged within 7 days.
- When the temperature is higher than 25°C, the system with excessive discharge shall be charged within 15 days.
- Long -term storage of lithium batteries will cause capacity loss. The longer the storage duration, the greater the capacity loss. Batteries may fail the discharge acceptance tests when their capacity after storage is less than 100% of the rated capacity.

13 Maintenance and Replacement

- Do not perform maintenance on the equipment unless you are familiar with the contents of this manual and have the proper tools and test equipment.
- Professional technicians and operators shall be fully trained and have knowledge of safe operation and maintenance of the equipment. They should take adequate precautions and personal protective equipment while operating.
- Before the equipment is repaired, the power must be cut off and the safety precautions in this manual and other relevant documents must be strictly observed.
- During maintenance, try to avoid irrelevant personnel entering the site.
- The unit cannot be powered up again until all faults have been resolved. Failure to do so may result in more problems or damage to the device.
- Do not open the cover without authorization, otherwise there is a risk of electric shock. Any faults caused by the above reasons are not covered by the warranty.
- Replace the battery with the same type.
- Immediately after completing maintenance, check to make sure no tools or other parts are left in the equipment.
- When the battery is idle for a long time, it must be stored and charged according to this manual.

To ensure that the battery system operates properly for a long term, you are advised to perform routine maintenance as described in this section.



Power off the system before cleaning the system, connecting cables, and checking grounding reliability.

Check Item	Check Method	Maintenance Interval
System cleanliness	Check periodically that the heat sinks are free from obstacles and dust.	Once every 6 to 12 months
System status	- Check whether the battery system is damaged or deformed. - Check whether there is abnormal sound when the battery system is running. - Check whether battery system parameters are correctly set when the battery system is running.	Once every 6 months
Electrical connection	- Check whether cables are securely connected. - Check whether cables are damaged, especially whether the cable sheath that contacts a metal surface is damaged. - Check whether unused DC input terminals, battery system terminals, and COM ports are locked by watertight caps	6 months after the first commissioning and once every 6 to 12 months after that
Grounding reliability	Check whether the PE cable is securely connected.	6 months after the first commissioning and once every 6 to 12 months after that

14 Disposal of Battery Module

Battery modules must be disposed of in accordance with applicable local regulations for the disposal of electronic waste and used batteries.

- Do not dispose of the battery module with household waste.
- Avoid exposing the battery to heat or direct sunlight.
- Avoid exposing the battery to high humidity or corrosive environments.

For more information, please contact.

15 Technical Parameters

PERFORMANCE				
	HVE 6.4	HVE 8.5	HVE 10.7	HVE 12.8-1
Battery Module	HVE 4.2 Module (4.29 kWh, 76.8 V, 42.6 kg), HVE 6.4 Module (6.43 kWh, 115.2 V, 61.6 kg)			
Number of Modules	1 (6)	2 (4+4)	2 (4+6)	2 (6+6)
Usable Energy ^[1]	6.43 kWh	8.58 kWh	10.72 kWh	12.86 kWh
Nominal Voltage	115.2 V	153.6 V	192.0 V	230.4 V
Operating Voltage	90 ~ 131.4 V	120 ~ 175.2 V	150 ~ 219 V	180 ~ 262.8 V
Dimensions(H/W/D)(mm)	794 x 660 x 140	986 x 660 x 140	1139 x 660 x 140	1292 x 660 x 140
Weight	73.1 kg	96.7 kg	115.7 kg	134.7 kg
				
	HVE 12.8-2	HVE 15.0	HVE 17.1-1	HVE 19.2
Number of Modules	3 (4+4+4)	3 (4+4+6)	3 (4+6+6)	3 (6+6+6)
Usable Energy ^[1]	12.87 kWh	15.01 kWh	17.15 kWh	19.29 kWh
Nominal Voltage	230.4 V	268.8 V	307.2 V	345.6 V
Operating Voltage	180 ~ 262.8 V	210 ~ 306.6 V	240 ~ 350.4 V	270 ~ 394.2 V
Dimensions(H/W/D)(mm)	1331 x 660 x 140	1484 x 660 x 140	1637 x 660 x 140	1791 x 660 x 140
Weight	139.3 kg	158.3 kg	177.3 kg	196.3 kg
				
	HVE 17.1-2	HVE 19.3	HVE 21.4	HVE 23.5
Number of Modules	4 (4+4+4+4)	4 (4+4+4+6)	4 (4+4+6+6)	4(4+6+6+6)
Usable Energy ^[1]	17.16 kWh	19.30 kWh	21.44 kWh	23.58 kWh
Nominal Voltage	307.2 V	345.6 V	384.0 V	422.4 V
Operating Voltage	240 ~ 350.4 V	270 ~ 394.2 V	300 ~ 438 V	330 ~ 481.8 V
Dimensions(H/W/D)(mm)	1677 x 660 x 140	1830 x 660 x 140	1983 x 660 x 140	2136 x 660 x 140
Weight	181.9 kg	200.9 kg	219.9 kg	238.9 kg

GENERAL DATA

Max.Charge and Discharge Current ^[2]	35 A
Peak Charge and Discharge Current ^[2]	70 A, 10 s
Scalability	Max. 3 in Parallel (70.74 kWh)
Installation Mode	Floor Stand (standard) / Wall Mount (optional)
Installation Scene	Indoor & outdoor installation
Communication	CAN / RS485
Round-trip Efficiency	≥ 95%
Applications	On Grid / On Grid + Backup / Off Grid
Operating Temperature	-20 °C to +55°C
IP Class	IP65
Cooling	Natural Convection
Storage Humidity	5%~95%
Altitude ^[3]	< 4000 m
Warranty ^[4]	15 Years
Accessories (Optional)	BYD Smart WIFI/LAN module, Wall-mounting Bracket
Certification	IEC 62619 / IEC 62040 / IEC 62477-1 / EN 61000-6-1/2/3/4 / EN 301489-1 / EN 301489-17/ EN 300328 / EN 62311 / VDE- AR-E 2510-50 / RCM / CEC / REACH / RoHS / UN38.3
Compatibilities	BYD Power-Box SH3-6K, BYD Power-Box TH5-15K

[1] DC Usable Energy, Test conditions: 0.2C charge & discharge at + 25°C.

[2] Charge derating will occur between -10°C and +10°C, discharge derating will occur between -20°C and +10°C.

[3] The output power may be affected by altitude. Please refer to the user manual for details.

[4] Conditions apply. Refer to BYD Battery-Box HVE Limited Warranty Letter

Note

A: 6.43kWh and 4.29kWh are the initial capacity (designed) of the Energy Storage Module.

B: The actual capacity is affected by the external environment (such as temperature, transportation, and storage).

16 Contact Information

BYD Global Service

Address: No.3009, BYD Road, Pingshan, Shenzhen, 5118118, P.R.China

Service Mailbox: bboservice1@fdbatt.com

Website: www.bydenery.com

BYD Authorized Service Partner

EFT-Systems GmbH

Address: Bruchtannenstraße 28, 63801 Kleinostheim

Service Mailbox: service@eft-systems.de

Telephone: +49 9352 8523999, +44 (0) 2037695998(UK) ,+34 91 060 22 67(ES)
+39 02 87368364(IT)

Website: www.eft-systems.de

BYD Authorized Service Partner

ALPS Power Pty Ltd

Address:2/62 Belmore Rd North, Riverwood NSW 2210

Service Mailbox: service@alpspower.com.au

Telephone:+61 2 8005 6688

Website: www.alpspower.com.au