



BYD Battery-Box LV Compatible Inverter List

Battery-Box L 3.5/7.0/10.5/14.0

Contents

- 1 Minimum configuration with different inverters..... 2**
 - 1.1 Minimum configuration with SMA Sunny Island inverter 2
 - 1.2 Minimum configuration with GOODWE inverter 3
 - 1.2.1 Minimum configuration with ES..... 3
 - 1.2.2 Minimum configuration with EM..... 3
 - 1.2.3 Minimum configuration with SBP..... 4
 - 1.3 Minimum configuration with Victron inverter 4
 - 1.3.1 Minimum configuration with Multiplus..... 4
 - 1.3.2 Minimum configuration with Multigrid 5
 - 1.3.3 Minimum configuration with Quattro..... 5
 - 1.3.4 Minimum configuration with CCGX of Easysolar..... 6
 - 1.4 Minimum configuration with SUNGROW 7
 - 1.4.1 Minimum configuration with SH5K..... 7
 - 1.5 Minimum configuration with Solis..... 8
 - 1.5.1 Minimum configuration with Solis 8
- 2 Common Failures Displayed on Inverter and Solution 9**
 - 2.1 Alarm code displayed on the SRC of SMA sunny island and solution 9
 - 2.2 Alarm displayed on the APP of GOODWE and the solution 10
- Contact Information 10**

1 Minimum configuration with different inverters

1.1 Minimum configuration with SMA Sunny Island inverter

Inverter Firmware version: minimum required firmware version for SI is V1.73.

BYD Battery-Box LV firmware version: minimum required firmware version for BCU is V1.0.

1 Phase on grid (Self consumption)

Inverter Type	B-Plus L 3.5	BCU
SI 3.0M	≥1	≥1
SI 4.4M	≥1	≥1
SI 6.0H	≥1	≥1
SI 8.0H	≥1	≥1

3 Phase on grid (Self consumption)

Inverter Type	B-Plus L 3.5	BCU
SI 3.0M	≥2	≥1
SI 4.4M	≥3	≥1
SI 6.0H	≥3	≥1
SI 8.0H	≥3	≥1

1 Phase on grid (Self consumption+ Backup)

Inverter Type	B-Plus L 3.5	BCU
SI 3.0M	≥3	≥1
SI 4.4M	≥4	≥1
SI 6.0H	≥6	≥2
SI 8.0H	≥7	≥2

3 Phase on grid (Self consumption+ Backup)

Inverter Type	B-Plus L 3.5	BCU
SI 3.0M	≥8	≥2
SI 4.4M	≥10	≥3
SI 6.0H		
SI 8.0H		

Remark:

1. Maximum quantity of B-Plus L 3.5 is 12, BCU quantity is 3.
2. Please refer to the *Discharging current in backup mode* in page 6, and make sure the discharging current in backup mode won't be more than the specified value.

1.2 Minimum configuration with GOODWE inverter

1.2.1 Minimum configuration with ES

Inverter Firmware version: minimum required firmware version for ARM is 03.

BYD Battery-Box LV firmware version: minimum required firmware version for BCU is V1.0.

1 Phase on grid (Self consumption)

Inverter Type	B-Plus L 3.5	BCU
GW3648D-ES	≥1	≥1
GW5048D-ES	≥1	≥1

1 Phase on grid (Self consumption+ Backup)

Inverter Type	B-Plus L 3.5	BCU
GW3648D-ES	≥2	≥1
GW5048D-ES	≥3	≥1

Remark:

1. Maximum quantity of B-Plus L 3.5 is 12, BCU quantity is 3.
2. Please refer to the *Discharging current in backup mode* in page 6, and make sure the discharging current in backup mode won't be more than the specified value.

1.2.2 Minimum configuration with EM

Inverter Firmware version: minimum required firmware version for ARM is 03.

BYD Battery-Box LV firmware version: minimum required firmware version for BCU is V1.0.

1 Phase on grid (Self consumption)

Inverter Type	B-Plus L 3.5	BCU
GW3048-EM	≥1	≥1
GW3648-EM	≥1	≥1
GW5048-EM	≥1	≥1

1 Phase on grid (Self consumption+ Backup)

Inverter Type	B-Plus L 3.5	BCU
GW3048-EM	≥1	≥1
GW3648-EM	≥1	≥1
GW5048-EM	≥1	≥1

Remark:

1. Maximum quantity of B-Plus L 3.5 is 12, BCU quantity is 3.
2. Please refer to the *Discharging current in backup mode* in page 6, and make sure the discharging current in backup mode won't be more than the specified value.

1.2.3 Minimum configuration with SBP

Inverter Firmware version: minimum required firmware version for ARM is 03.

BYD Battery Box LV firmware version: minimum required firmware version for BCU is V1.0

1 Phase on grid (Self consumption)		
Inverter Type	B-Plus L 3.5	BCU
GW3600S-BP	≥1	≥1
GW5000S-BP	≥1	≥1

1 Phase on grid (Self consumption+ Backup)		
Inverter Type	B-Plus L 3.5	BCU
GW3600S-BP	≥2	≥1
GW5000S-BP	≥3	≥1

Remark:

1. Maximum quantity of B-Plus L 3.5 is 12, BCU quantity is 3.
2. Please refer to the *Discharging current in backup mode* in page 6, and make sure the discharging current in backup mode won't be more than the specified value.

1.3 Minimum configuration with Victron inverter

1.3.1 Minimum configuration with Multiplus

Inverter Firmware version: minimum required firmware version for CCGX is V2.01, which applies to ESS mode.

BYD Battery-Box LV firmware version: minimum required firmware version for BCU is V1.0, which applies to ESS mode.

1 Phase on grid (Self consumption)		
Inverter Type	B-Plus L 3.5	BCU
48/3000/35	≥1	≥1
48/5000/70	≥1	≥1

3 Phase on grid (Self consumption)		
Inverter Type	B-Plus L 3.5	BCU
48/3000/35	≥2	≥1
48/5000/70	≥2	≥1

1 Phase on grid (Self consumption+ Backup)		
Inverter Type	B-Plus L 3.5	BCU
48/3000/35	≥3	≥1
48/5000/70	≥5	≥2

3 Phase on grid (Self consumption+ Backup)		
Inverter Type	B-Plus L 3.5	BCU

48/3000/35	≥7	≥2
48/5000/70	≥12	≥3

Remark:

1. Maximum quantity of B-Plus L 3.5 is 12, BCU quantity is 3.
2. Please refer to the *Discharging current in backup mode* in page 6, and make sure the discharging current in backup mode won't be more than the specified value.

1.3.2 Minimum configuration with Multigrid

Inverter Firmware version: minimum required firmware version for CCGX is V2.01, which applies to ESS mode.

BYD Battery- Box LV firmware version: minimum required firmware version for BCU is V1.0, which applies to ESS mode.

1 Phase on grid (Self consumption)

Inverter Type	B-Plus L 3.5	BCU
48/3000/35	≥1	≥1

3 Phase on grid (Self consumption)

Inverter Type	B-Plus L 3.5	BCU
48/3000/35	≥2	≥1

1 Phase on grid (Self consumption+ Backup)

Inverter Type	B-Plus L 3.5	BCU
48/3000/35	≥3	≥1

3 Phase on grid (Self consumption+ Backup)

Inverter Type	B-Plus L 3.5	BCU
48/3000/35	≥7	≥2

Remark:

1. Maximum quantity of B-Plus L 3.5 is 12, BCU quantity is 3.
2. Please refer to the Discharging current in backup mode in page 6, and make sure the discharging current in backup mode won't be more than the specified value.

1.3.3 Minimum configuration with Quattro

Inverter Firmware version: minimum required firmware version for CCGX is V2.01, which applies to ESS mode.

BYD Battery- Box LV firmware version: minimum required firmware version for BCU is V1.0, which applies to ESS mode.

1 Phase on grid (Self consumption)

Inverter Type	B-Plus L 3.5	BCU
48/5000/70-100/100	≥1	≥1

48/8000/110-100/100	≥1	≥1
48/10000/140- 100/100	≥1	≥1
48/15000/200- 100/100	≥1	≥1

3 Phase on grid (Self consumption)

Inverter Type	B-Plus L 3.5	BCU
48/5000/70-100/100	≥2	≥1
48/8000/110-100/100	≥3	≥1
48/10000/140- 100/100	≥4	≥2
48/15000/200- 100/100	≥5	≥2

1 Phase on grid (Self consumption+ Backup)

Inverter Type	B-Plus L 3.5	BCU
48/5000/70-100/100	≥5	≥2
48/8000/110-100/100	≥7	≥2
48/10000/140- 100/100	≥9	≥3
48/15000/200- 100/100	≥11	≥3

3 Phase on grid (Self consumption+ Backup)

Inverter Type	B-Plus L 3.5	BCU
48/5000/70-100/100	≥11	≥3
48/8000/110-100/100 ¹	/	/
48/10000/140- 100/100	/	/
48/15000/200- 100/100	/	/

Remark:

1. Maximum quantity of B-Plus L 3.5 is 12, BCU quantity is 3.
2. Please refer to the *Discharging current in backup mode* in page 6, and make sure the discharging current in backup mode won't be more than the specified value.

1.3.4 Minimum configuration with CCGX of Easysolar

Inverter Firmware version: minimum required firmware version for CCGX is V2.01, which applies to ESS mode.

BYD Battery-Box LV firmware version: minimum required firmware version for BCU is V1.0, which applies to ESS mode.

1 Phase on grid (Self consumption)

Inverter Type	B-Plus L 3.5	BCU
---------------	--------------	-----

¹ The configuration in back up mode is calculated based on the max back up power of inverter, and the loads power shouldn't be more than the battery max power. The efficiency ratio between the loads and inverter should be considered.

48/3000/35-50 MPPT150/70	≥1	≥1
48/5000/70-100 MPPT150/100	≥1	≥1
3 Phase on grid (Self consumption)		
Inverter Type	B-Plus L 3.5	BCU
48/3000/35-50 MPPT150/70	≥2	≥1
48/5000/70-100 MPPT150/100	≥2	≥1
1 Phase on grid (Self consumption+ Backup)		
Inverter Type	B-Plus L 3.5	BCU
48/3000/35-50 MPPT150/70	≥3	≥1
48/5000/70-100 MPPT150/100	≥5	≥2
3 Phase on grid (Self consumption+ Backup)		
Inverter Type	B-Plus L 3.5	BCU
48/3000/35-50 MPPT150/70	≥7	≥2
48/5000/70-100 MPPT150/100	≥12	≥3

Remark:

1. Maximum quantity of B-Plus L 3.5 is 12, BCU quantity is 3.
2. Please refer to the *Discharging current in backup mode* in page 6, and make sure the discharging current in backup mode won't be more than the specified value.

1.4 Minimum configuration with SUNGROW

1.4.1 Minimum configuration with SH5K

Inverter Firmware version: minimum required firmware version is V13.

BYD Battery Box LV firmware version: minimum required firmware version for BCU is V1.0.

Identification label on package is L2.1

1 Phase on grid (Self consumption)		
Inverter Type	B-Plus L 3.5	BCU
SH5K	≥1	≥1
1 Phase on grid (Self consumption+ Backup)		
Inverter Type	B-Plus L 3.5	BCU
SH5K	≥3	≥1

Remark:

1. Maximum quantity of B-Plus L 3.5 is 12, BCU quantity is 3.
2. Please refer to the *Discharging current in backup mode* in page 6, and make sure the discharging current in backup mode won't be more than the specified value.

1.5 Minimum configuration with Solis

1.5.1 Minimum configuration with Solis

Inverter Firmware version: minimum required firmware version is 11000F.

BYD Battery Box LV firmware version: minimum required firmware version for BCU is V1.2

Identification label on package is L2.1

1 Phase on grid (Self consumption)

Inverter Type	B-Plus L 3.5	BCU
RHI-3K-48ES	≥1	≥1
RHI-3.6K-48ES	≥1	≥1
RHI-4.6K-48ES	≥1	≥1
RHI-5K-48ES	≥1	≥1

1 Phase on grid (Self consumption+ Backup)

Inverter Type	B-Plus L 3.5	BCU
RHI-3K-48ES	≥2	≥1
RHI-3.6K-48ES	≥2	≥1
RHI-4.6K-48ES	≥2	≥1
RHI-5K-48ES	≥2	≥1

Remark:

1. Maximum quantity of B-Plus L 3.5 is 12, BCU quantity is 3.
 2. Please refer to the *Discharging current in backup mode* in page 6, and make sure the discharging current in backup mode won't be more than the specified value.
-
-

2 Common Failures Displayed on Inverter and Solution

2.1 Alarm code displayed on the SRC of SMA sunny island and solution

SMA SRC	Possible causes	Solution
F221	External Alarm-Invalid Bat Type	Reset battery type to "Li" on SRC.
F920(XA01General)	1.Any B-Plus L3.5 has failed to communicate with the BCU;	1. Check if the modules are connected correctly and all screws are fixed tightly. 2.Replace BCU ;
F921(XA02DcHiVolt)	External Alarm - Battery High Voltage	If the orange LED of the BCU is on, please contact the service provider to change the battery. If not, check the system setting according to the guidelines.
F922(XA03DcLoVolt)	External Alarm - Battery Low Voltage	System will recovery automatically
F923(XA04DcHiTmp)	External Alarm - Battery High Temp	System will recovery automatically
F924(XA05DcLoTmp)	External Alarm - Battery Low Temp	System will recovery automatically
F925(XA06DcHiTmpC)	External Alarm - Battery High Temp Charge	System will recovery automatically
F926(XA07DcLoTmpC)	External Alarm - Battery Low Temp Charge	System will recovery automatically
F927(XA08DcHiCur)	External Alarm - Battery High Current Discharge	System will recovery automatically
F928(XA09DcHiChgCur)	External Alarm - Battery High Current Charge	System will recovery automatically
F930(XA11Short)	External Alarm - Short circuit	1.Power off; 2.Check if batteries are short connected; 3.If short connection is confirmed, then reconnect cables correctly, and restart battery;

F931(XA12Bms)	External Alarm - BCU internal	If the orange LED of the BCU is lit, please contact the service provider to replace the battery. If not, check the system settings according to the guidelines.
F932(XA13CellBal)	External Alarm - Cell imbalance	System will recovery automatically
F952	External Alarm –Ext BCU Timeout	1.Check if the CAN communication cables are connected correctly and tightly ; 2.Replace BCU if the problem still exist after checking;

2.2 Alarm displayed on the APP of GOODWE and the solution

APP of GOODWE	Possible causes	Solution
BMS status: Battery communication fail	Inverter and BCU communication failure	1.Check if the CAN communication cables are connected correctly and tightly ; 2.Replace BCU if the problem still exist after checking ;

MEMO

Contact Information

China

BYD LITHIUM BATTERY Co., LTD

E-Mail: eubatterygrp@byd.com

Tel: +86 0755 89888888

Fax: 0755-8961 9653

Address: No.1 Baoping Road, Baolong Industrial Town, Longgang Shenzhen, 518116, China

Local Service Provider

Australia

Alps Power Pty Ltd

14/47-51 Lorraine St Peakhurst NSW 2114

Customer Service Mailbox: service@alpspower.com.au

+61 2 8005 6688

www.alpspower.com.au

Europe

EFT-Systems GmbH

Buchenstr.37 97816 Lohr a. Main

Customer Service Mailbox: service@eft-systems.de

+49 9352 8523999(DE)

+34 91 0602267 (ES)

+39 02 87368364 (IT)

+44 2037695998 (UK)

www.eft-systems.de